


PRO CONCRETE SPRAYER REPLACEMENT PARTS



PARTS LIST
1. TANK
2. WAND HOLSTER
3. INLET TUBE
4. O RING SEAL
5. NUT
6. O RING SEAL
7. HOSE
8.END CAP
9. PLASTIC FILTER
10. O RING SEAL
11. END CAP
12. O RING SEAL
13. SPRING
14. SPINDLE
15. O RING SEAL
16. O RING SEAL
17. O RING SEAL
18. HANDLE HOUSING & TRIGGER
19. O RING SEAL
20. WAND
21. O RING SEAL
22. NOZZLE
23. RELIEF VALVE
24. PUMP HANDLE D PLUNGER
25. BRASS WASHER
26. WASHER
27. GASKET
28. BARREL
29. CHECK VALVE

PRODUCT CODE	BARCODE	SIZE
OX-P049301	OX Brass Fan Nozzle - 1.0 GPM (3.8LPM)	22
OX-P049302	OX 600mm Stainless Steel Spray Wand	19, 20 & 21
OX-P049303	OX Trigger Assembly	8, 9, 10, 11, 12, 13, 14, 15, 16, 17 & 18
OX-P049304	OX 1200mm Chemical Resistant Hose with Connections	6 & 7
OX-P049305	OX Genuine OXSeal and Gasket Kit	4, 6, 10, 12, 15, 16, 17, 19, 21, 25, 26, 27 & 29
OX-P049306	OX Stainless Steel Pump Assembly	24, 25, 26, 27, 28 & 28
OX-P049307	OX Plunger Assembly	24 & 25
OX-P049310	OX Supply Tube Assembly	3, 4 & 5